

# CVE 307 HANDOUT NOTES

1st lecture WE 307


12/01/2018 Friday (2-4) Tuesday

### ADVANCE TOPIC IN BENDING MOMENT AND SHEAR (P) FORCE IN BEAMS.


What is Shear force? Algebraic sum of the vertical forces at any section of a beam to the right or left of the section.

What is BM? Algebraic sum of the moments of all the forces acting to the right or left of the section.

#### SIGN CONVENTIONS



Positive shear force



Negative shear force

Concavity at Top



Sagging

Positive B.M.

Convexity at Top



Hogging

Negative B.M.

WE 307

2019/2020


PS 1

Tue - Wed 1/2/2020

CVE 307 Lect 18

WITH POINT SHEAR FORCE & BM FOR A CANTILEVER LOAD AT THE

Problem 1. A cantilever beam of length 2m carries the point load as shown below. Draw the shear force and B.M diagrams for the cantilever beam.



Shear force Diagram -

SF at D = +8kN. This S.F remains constant between D and C. At C, due to point load, the shear force becomes:  $(8+5) = 13\text{kN}$ . Between C and B, the shear force remains 13kN. At B again, S.F becomes  $13+3 = 16\text{kN}$ . S.F between B and A remains constant and equal to 16kN. Hence

$$\text{SF at D} = F_D = +8\text{kN}$$

$$\text{SF at C} = F_C = +8 + 5 = +13\text{kN}$$

$$\text{SF at B} = F_B = +13\text{kN} + 3 = +16\text{kN}$$

$$\text{SF at A} = F_A = +16\text{kN}$$


20/9/2020 Pg 2  
11/07/2020

SF Diagram.

Draw a horizontal line AD as base line. On the base line (AD) mark the points B and C below the point loads. Take ordinate DE = 8kN in the upward direction. Draw EF parallel to AD. The point F is vertically above C. Take vertical line FG = 5kN. Through G, draw a horizontal line GH in which point H is vertically above B. Draw vertical line HI = 3kN. From I draw a horizontal line. The point J is vertically above A. This completes the shear force diagram.

Bending moment.

B.M. at D :  $M_D = 0$



B.M. at any section between C & D at a distance  $x$  from D is given by

$$M_x = -8x \text{ which follows a straight line law}$$

At C :  $x = 8\text{m}$   $M_C = -8 \times 8 = -64 \text{ kNm}$

(ii) B.M. at any section b/w B and C at a distance  $x$  from D is given by

$$M_x = -8x - 5(x-8) - 3(x-15)$$

At D :  $x = 8\text{m}$  and at B,  $x = 8 + 7\text{m} = 15\text{m}$ .


Hence here  $x$  varies from 8 to 15

$$M_x = -8x - 5(x-8)$$

B.M. between B and C also varies by a straight line law

B.M. at B is obtained by substituting  $x = 15\text{m}$ .


$$\therefore M_B = -8 \times 15 - 5(15-8) = -120 - 35 = -155 \text{ kNm}$$



at  $x = 15\text{m}$ .

2019 2020 P3-3

(iii) B.M at any section between A and B at a distance  $x$  from D is given by



$$M_x = -8x - 5(x-8) - 3(x-15)$$

B.M btw A and B varies by a straight line law.

B.M at A is obtained by substituting  $x = 20m$

$$M_A = -8 \times 20 - 5(20-8) - 3(20-15) \\ = -160 - 60 - 15 = -235 \text{ kNm}$$

B.M diagram

Draw a horizontal line AD as a base line and mark the points B and C on this line. Take vertical lines  $CC' = 60 \text{ kNm}$ ,  $BB' = 155 \text{ kNm}$  and  $AA' = 235 \text{ kNm}$  in the downward direction. Join D, C', B', A by straight lines. This completes the B.M diagram.

(2) SF & BM Diagram for a SSB WITH AN ECCENTRIC POINT LOAD.




A SSB of length 6m carries point load of 3kN and 6kN at distances of 2m and 4m from left end. Draw S.F and B.M diagrams for the beam.

PS of 11/02/2020

CW307

17/18

P53



Reactions

$$\sum M_A = 0$$

$$R_B \times 6 = 3 \times 2 + 6 \times 4$$

$$6R_B = 30$$

$$R_B = \underline{5\text{ kN}}$$

$$R_A = 9 - 5 = \underline{4\text{ kN}}$$

BM

At A,  $M_A = 0$

At C,  $M_C = R_A \times 2 = +8\text{ kNm}$

At D,  $M_D = R_A \times 4 - 3 \times 2$   
 $= 8 \times 4 - 3 \times 2 = +10\text{ kNm}$

$M_B = 0$  or

$M_B = R_A \times 6 - 3 \times 4 - 6 \times 2$   
 $= 24 - 12 - 12 = 0$

proved

SF Diagram

At A,  $F_A = +4\text{ kN}$

At C,  $F_C = +4 - 3 = +1\text{ kN}$

At D,  $F_D = +1 - 6 = -5\text{ kN}$

At B,  $F_B = -5\text{ kN}$

Shear F- $\Delta$  w A & C is constant = +4kN

SF  $\Delta$  w C & D is constant = +1kN

SF  $\Delta$  w D & B is constant = -5kN.

SF at B =  $F_B = -5\text{ kN}$ ,

11/02/2020

P53


307 18/12/2017 17/18

③

SF & BM For A UDL

A Simply Supported beam 5m long with a UDL of 10kN/m over a length of 2m as shown below -

Draw SF & BM diagrams for the beam indicating the value of maximum bending moment  $B_{max}$ .



Reaction

$$\sum M_A = 0$$

$$5 \times R_B = 10 \times 2 \times \left(\frac{2+1}{2}\right)$$

$$5R_B = 10 \times 2 \times 2$$

$$5R_B = 40$$

$$R_B = 8 \text{ kN}$$

$$R_A = (10 \times 2) - 8$$

$$R_A = 12 \text{ kN}$$

SF

$$\text{At A ; } F_A = +12 \text{ kN}$$

$$\text{At C ; } F_C = +12 \text{ kN}$$

$$\text{At D ; } F_D = +12 - 10 \times 2 = -8 \text{ kN}$$

$$\text{At B ; } F_B = -8 \text{ kN}$$

pg 6 11/02/2020

19/3/19 done

B.M

At A,  $M_A = 0$

At C,  $M_C = R_A \times 1 = 12 \text{ kNm}$

At D,  $M_D = R_A \times 3 - 10 \times 2 \times 1$

$= 36 - 20 = 16 \text{ kNm}$

At B,  $M_B = 0$

OR

$M_B = R_A \times 5 - 10 \times 2 \times \left[ \frac{2+2}{2} \right]$

$= 60 - (20 \times 3) = 0$

proved.

To find  $M_{max}$

$M_{max}$  occurs at a point where SF changes sign i.e. where SF is zero

From SFD - let  $x$  represent the distance between C and  $M_{max}$  - from the geometry of the figure between C and D

SF btw A & C constant &

still constant = +12 kN

SF btw C & D changes to -8 kN at D.

Shear F btw D & B constant = -8 kN.

11/02/2020 PT

Ques 3 of

We find that

P39

$\frac{x}{12} = \frac{2-x}{8}$

$8x = 24 - 12x$

$20x = 24$


$x = 1.2 \text{ m}$

$M_{max} = R_A (1+x) - 10 \times x \times \frac{x}{2}$

$= 12 (1+1.2) - 10 \times 1.2 \times \frac{1.2}{2}$

$= 19.2 \text{ kNm}$

OR



$R_A = 10x + V$

$12 = 10x + V$

$V = 12 - 10x$

at  $V = 0$

$12 - 10x = 0$

$x = 1.2 \text{ m}$

$R_A (1+x) - 10 \times \frac{x^2}{2} = M_{max}$

at  $x = 1.2$   $M_{max} =$


$= 19.2 \text{ kNm}$

2019/2020 - Lecture 1 ends

V19/3/19 done

## Relations Btw load, Shear Force and Bending moment.

Figure below showed a beam carrying a load of  $w$  per unit length. Consider the equilibrium of the portion of the beam btw sections 1-1 and 2-2. This portion is at a distance  $x$  from left supports and is of length  $dx$ .



$V$  = Shear  $F$  at Section 1-1

$V+dV$  = SF at Section 2-2

$M$  = BM at Section 1-1

$M+dM$  = BM at Section 2-2

Therefore, the forces and moments acting on the length  $dx$  of the beam are.

Equilibrium of forces in vertical direction is given as

$$V - w dx - (V + dV) = 0$$

$$V - w dx - V - dV = 0$$

$$-dV = w dx$$

$$\frac{dV}{dx} = -w$$

above ~~the~~ equation shows that the rate of change

Pg 5

of shear force (V) is equal to the rate of loading (w)

Integrating

$$\therefore \int_A^B dV = \int_A^B -w dx$$

$$\therefore V_B - V_A = - \int_A^B w dx$$

Area of loading diagram between A & B

The area of loading diagram may be +ve or negative.

Moment equilibrium of element

$$M - w dx \cdot \frac{dx}{2} + V dx = M + dM$$

$$M - \frac{w dx^2}{2} + V dx = M + dM$$

$$dM = - \frac{w dx^2}{2} + V dx$$

$dx$  is infinitesimally small therefore the higher powers will tend to zero!

$$\therefore dM = V dx$$

$$\frac{dM}{dx} = V \implies V = \frac{dM}{dx}$$

Maximum or Minimum BM occurs at  $\frac{dM}{dx} = 0$



$$\text{at } V = 0$$

19/3/19

The above equation shows that the rate of change of BM is equal to the SF of the section.

Problem

A SSB of length 10m carries UDL and two point loads as shown below. Draw S.F and B.M diagrams for the beam. Also calculate the maximum bending moment.



$$\frac{x}{30} = \frac{4-x}{10} \quad x = 3m$$

$$M = R_A(2+x) - 5x - 10x \times \frac{x}{2}$$

P56

Reactions

$$\sum F_{13} = 0$$

$$10R_A = 50 \times 8 + 40 \times 4 + 10 \times 4 \times 6$$

$$= 400 + 160 + 240$$

$$10R_A = 800$$

$$R_A = 80 \text{ kN}$$

$$R_A + R_B = 50 + 40 + 40$$

$$R_B = 130 - 80$$

$$= 50 \text{ kN}$$

SF

$$V_A = +80 \text{ kN}$$

$$V_E = +80 - 50 = +30 \text{ kN}$$

$$V_D = +30 - 10 \times 4 - 40 = -50 \text{ kN}$$

$$V_B = -50 \text{ kN}$$

BM

$$M_A = 0$$

$$M_E = 80 \times 2 = 160 \text{ kNm}$$

$$M_D = 80 \times 6 - 50 \times 4 - 10 \times 4 \times 2$$

$$= 480 - 200 - 80$$

$$M_D = 200 \text{ kNm}$$

$$M_B = 0$$

$M_{max}$  occurs at

$$\text{where } V = 0$$

$$\text{Geometry } \frac{x}{30} = \frac{4-x}{40}$$

$$40x = 120 - 30x$$

$$40x = 120$$

$$x = \frac{120}{70} = 1.71 \text{ m}$$

Let distance E from A = x

Shear force at E =  $V_E$

$$V_E = R_A - 50 - 10(x-2)$$

$$= 80 - 50 - 10x + 20$$

$$V_E = 50 - 10x$$

at  $V_E = 0$ ,  $M_{max}$  occurs

$$50 - 10x = 0$$

$$x = 5 \text{ m}$$

$$M_E = R_A(2+x) - 50x - 10 \frac{x^2}{2}$$

$M_{max}$  at  $x = 5 \text{ m}$

$$M_{max} = 80 \times 7 - 50 \times 5 - 10 \times 5^2$$

$$= 560 - 250 - 125$$

$$M_E = R_A x - 50(x-2) - 10 \frac{(x-2)^2}{2}$$




$$= 80 \times 5 - 50 \times 3 - 80 \times 3$$

$$= 400 - 150 - 45$$

$$= 205 \text{ kNm}$$

Ques 3.7

23/01/18 Monday



Reaction

$$\sum M_B = 0$$

$$4.6 R_A - 30.83 \times 4.6 \times 4.6 \times \frac{1}{2} = 0$$

$$4.6 R_A = 326.18$$

$$R_A = 70.91 \text{ kN}$$

$$R_A + R_B = 30.83 \times 4.6$$

$$R_B = 141.818 - 70.91$$

$$R_B = 70.91 \text{ kN}$$

SF

At A,  $V_A = 70.91$

At C,  $V_C = 70.91 - 30.83 \times 2.3$

~~$V_C = 70.91 - 70.91$~~

①  
beginning

At B,  $V_B = 0 - 70.91$

$$= -70.91 \text{ kN}$$

Bending moment

$$M = R_A x - \frac{30.83 x^2}{2}$$

At A,  $M_A = 0$

At C,  $M_C = 70.91 \times 2.3 - \frac{30.83 \times 2.3 \times 2.3}{2}$

$$= 163.093 - 81.54$$

$$M_C = 81.54 \text{ kNm}$$

$M_B = 0$

or

~~$$M_C = 70.91 \times 2.3 - \frac{30.83 \times 2.3 \times 2.3}{2}$$~~

$$= 326.186 - 326.1814$$

$$= 0$$

$M_{\text{max}}$  occurs at a point when  $V = 0$

Let distance  $x$  from A be

$x =$

we should know that

$x = 2.3$  (Verify)

or

$$V_C = R_A - 30.83 x$$
~~$$V_C = 70.91 - 30.83 x$$~~

or  $R_A - 30.83 x - V_C = 0$

Ps 7 (27)

①  
SOM

~~$70.91 - 30.8x^2 = V_c$~~

$70.91 - 30.8x = V_c$

at  $V_c = 0$

$30.8x = 70.91$

$x = 2.3 \text{ m}$

$H_{max} = Mc$

~~$R_A x - 30.83 x \cdot x = M_{max}$~~


$70.91x - 30.83 \frac{x^2}{2} = M_{max}$

at  $x = 2.3$


$163.093 - 81.54$

$M_{max} = 81.54 \text{ kcal m}$


② Simply supported with Gradually Varying load



Total load = Area of Triangle  
 $\frac{1}{2} B \times H$



SFD



Reaction:  $\sum F_B = 0$   
 $48 R_A - \left[ \frac{1}{2} \times 48 \times 4 \right] \times \frac{1}{3} \times 4 = 0$

$R_A = \frac{128}{4} = 32 \text{ kN}$

$R_B = \left[ \frac{1}{2} \times 48 \times 4 \right] - 32 = 64 \text{ kN}$

Centroid of or Centre of Gravity CG

(Here) Centroid and C.G. are at the same point.

C.G. of a body is the point through which the whole weight of the body acts.


Centroid: The point at which the total area of a plane figure (rectangle, square, triangle, quadrilateral, circle etc) is assumed to be concentrated is called the centroid of that area.

$$y = x^n : \frac{dy}{dx} = nx^{n-1}$$

Shear force

$$\text{At } A : V_A = 32 \text{ kN}$$

$$\text{At } C : V_C = 32 - 6x^2$$



$$R_A = 32 \text{ kN}$$

Similar  $\Delta$

$$\frac{y}{x} = \frac{48}{4}$$

$$\frac{y}{x} = 12$$

$$y = 12x$$

$$V_C = R_A - \frac{1}{2} \times (y+x)$$

$$= R_A - \frac{1}{2} \times 12x \times x$$

$$V_C = R_A - 6x^2$$

At C = Shear force is equal to zero (Noted)

$$\text{i.e. } R_A - 6x^2 = 0$$

$$6x^2 = 32$$

$$x^2 = 5.3$$

$$x = 2.309 \text{ m}$$

$$V_C = 32 - 6(2.309)^2$$

$$V_C = 0$$

$$\textcircled{2} \quad y = ax^n : \frac{dy}{dx} = nx^{n-1}$$

$$V_C = 0 - 64$$

$$= -64 \text{ kN}$$

B.M

$$\text{At } A \quad M_A = 0 \quad (\text{ok})$$

$$\text{At } C \quad M_C = R_A \times 2.309$$

$$= \frac{y \times x \times L}{2 \times 3}$$

$$M_C = R_A x - \frac{1}{2} \times 12x^2 \times x^2$$

61

$$M_C = R_A x - 2x^3$$

$$\text{At } x = 2.309, M_C = M_{\text{max}}$$

$$M_{\text{max}} = 32 \times 2.309 - 2(2.309)^3$$

$$= 73.888 - 24.621$$

$$= 49.27 \text{ kNm} \quad \text{Ans}$$

Give Student Assignment

$$M = \int V$$

$$V = R_A - \frac{y \times x}{2}$$

$$y = 12x$$

$$V = R_A - 6x^2$$

$$M = \int V$$

$$M = R_A x - 2x^3$$

$$V = \frac{dM}{dx}$$

$$V = R_A - 6x^2$$

$$\int x^n dx = \frac{x^{n+1}}{n+1} + C \quad (n \neq -1)$$

Summary

# WE 307 BENDING STRESS IN SYMMETRICAL SECTIONS


WE 307

The neutral axis (N.A) of a Symmetrical Sections such as Circular, rectangular or Square) lies at a distance  $d/2$  from the outermost layer of the section where  $d$  is the diameter (for circular section) or depth for a rectangular or a square sections.

— There is no stress at the N.A. but stress at a point is directly proportional to its distance from the N.A.

— The maximum stress takes place at the outermost layer.

— For a SSB, there is a compressive stress above the N.A. and tensile stress below.



If we plot the stresses in a SSB section, we shall get the figure above.

Pg 1

13

~~14~~

# Bending Stress in

## Asymmetrical Sections

In case of Symmetrical sections, ~~The geometrical centre of the~~ the N.A passes through the geometrical centre of the sections. But in case of Unsymmetrical sections such as L, T sections, the Neutral axis do not pass through the geometrical centre of the sections.

Hence the value of  $y$  (distance from the N.A to the outermost part) for the topmost layer or bottom layer of the section from the N.A won't be the same.

As we know, for finding the bending stress in the beam, the bigger




(Pg 2)

Something is Excluded Symmetrical has corresponding similar parts. In other words, one side is the same as the other


- If you can draw a line down the center of something and get two similar halves: it is Symmetrical

## Lines of Symmetry



Excluded

Square has 4 lines of symmetry.



Rectangle

2 lines of symmetry.

P



Value of  $y$  is used.

As N.A passes through the Centre of gravity of the section, hence, in unsymmetrical section, first the C.G is calculated first.


### C.G

Centre of gravity of a body is the point through which the whole weight of the body acts.

A body is having only one C.G for all positions of the body.

It is represented by C.G or simply G.


Pg 3




Equilateral triangle  
3 lines of symmetry.




Isosceles triangle  
1 line of symmetry.




Trapezoid  
No lines of symmetry.




Parallelogram  
No lines of symmetry.




① C.G for a uniform rod lies at its middle point




② C.G for a triangle lies at the point where the three medians of the triangle meet.




③ C.G of rectangle, parallelogram is at the point where its diagonals meet each other.




Rectangle



Square






Parallelogram



Since there are an infinite number of lines through the centre, the circle has an infinite number of lines of symmetry.

⇓  
It is also the point of intersection of the line joining the middle points of the opposite sides



④ The C.G of a circle is at its centre

P54



# Unsymmetrical section




Figure above shows a plane figure of total area A where centre of gravity is to be determined.

Let area A composed of a number of small areas

i.e.

$$A = a_1 + a_2 + a_3 + a_4 + \dots$$

Let  $x_1$  = distance of C.G. of area  $a_1$  from OY axis

$x_2$   
 $x_3$   
 $x_4$  } Similarly.

and so on.

(Pg 5)

Moments of all small areas about the axis OY

$$= a_1 x_1 + a_2 x_2 + a_3 x_3 + a_4 x_4 + \dots$$

Let G be the centre of gravity of total Area A whose distance from the axis OY is  $\bar{x}$

The moment of total area about OY =  $A \bar{x}$

The moment of all small areas about the axis OY must be equal to the moment of total Area about the same axis

(17)

Here

$$a_1 x_1 + a_2 x_2 + a_3 x_3 + a_4 x_4 + \dots$$

$$A \bar{x}$$

$$\bar{x} = \frac{a_1 x_1 + a_2 x_2 + a_3 x_3 + a_4 x_4 + \dots}{A}$$

by Integration Method  
or summation method


CG of Areas of plane  
figures is given by

$$\bar{x} = \frac{\sum a_i x_i}{\sum a_i}$$

Taking moments of

Small areas about the  
axis OX

$$\bar{y} = \frac{\sum a_i y_i}{\sum a_i}$$



Where

$$i = 1, 2, 3, 4, \dots$$

$x_i$  = distance of CG of  
area  $a_i$  from axis OY

$y_i$  = distance of CG of  
area  $a_i$  from axis OX

pg 6



$y_1$  = distance of C.G. of area  $a_1$  from the bottom line GF

$$= 10 + \frac{3}{2} = 11.5 \text{ cm}$$

$y_2$  = distance of C.G. of area  $a_2$  from bottom line GF

$$y_2 = \frac{10}{2} = 5 \text{ cm}$$

Pg 76

$$\bar{y} = \frac{36 \times 11.5 + 30 \times 5}{66} \text{ cm}^3$$

$$= \frac{414 + 150}{66}$$

$$\bar{y} = 8.545 \text{ cm}$$


$$\bar{x} = \frac{a_1 x_1 + a_2 x_2}{a_1 + a_2}$$

$$= \frac{20 \times 10 + 16 \times 4}{36}$$


$$= \frac{200 + 64}{36} =$$

Ex

Find the Centre of Gravity of T-Section below.



The T-Section is Symmetrical about axis  $\gamma-\gamma$ . The section can also be split into (divided) two rectangles ABCD & EFGH.



Hence the C.G. of the section will lie on axis  $\gamma-\gamma$  since it is symmetrical about axis  $\gamma-\gamma$ .

The lowest line of the figure is G-F. Hence moments of the area will be taken about the line G-F.

$\bar{y}$  = distance of C.G. of the T-Section from bottom line G-F.


$$a_1 = \text{area of } \square ABCD = 3 \times 12 = 36 \text{ cm}^2$$

$$a_2 = \text{area of } \square EFGH = 10 \times 3 = 30 \text{ cm}^2$$

$$\bar{y} = \frac{a_1 y_1 + a_2 y_2}{A}$$

$$A = a_1 + a_2 = 66 \text{ cm}^2$$

Pg 8



Soln

The section is symmetrical about Y-Y axis.

$$a_1 = \text{Area of } \square ABCD$$

$$= 10 \times 2 = 20 \text{ cm}^2$$

$$a_2 = \text{Area of } \square EFGH$$

$$= 2 \times 15 = 30 \text{ cm}^2$$

$$a_3 = \text{Area of } \square JKLM$$

$$= 2 \times 20 = 40 \text{ cm}^2$$

$$y_1 = 17 + \frac{2}{2} = 18 \text{ cm}$$

$$y_2 = 2 + \frac{15}{2} = 9.5 \text{ cm}$$

$$y_3 = \frac{2}{2} = 1 \text{ cm}$$

$$\bar{y} = \frac{a_1 y_1 + a_2 y_2 + a_3 y_3}{A}$$

A


$$A = a_1 + a_2 + a_3$$

$$= 20 + 30 + 40 = 90 \text{ cm}^2$$

$$\bar{y} = \frac{20 \times 18 + 30 \times 9.5 + 40 \times 1}{90} \text{ (cm)}^3$$

$$\bar{y} = \frac{360 + 285 + 40}{90} \text{ cm}^3$$

$\bar{y} = 7.61 \text{ cm}$  from the lowest line LK.



pg 9



$$q_1 = 200 \times 2 = 4000 \text{ cm}^2$$

$$q_2 = 360 \times 20 = 7200 \text{ cm}^2$$

$$q_3 = 200 \times 20 = 4000 \text{ cm}^2$$

$$A = q_1 + q_2 + q_3 \\ = 15200 \text{ cm}^2$$

$$y_1 = 380 + \frac{20}{2} = 390 \text{ cm}$$

$$y_2 = 20 + \frac{360}{2} = 200 \text{ cm}$$

$$y_3 = \frac{20}{2} = 10 \text{ cm}$$


$$\bar{y} = \frac{q_1 y_1 + q_2 y_2 + q_3 y_3}{A} \quad (\text{cm}^3 / \text{cm}^2)$$

$$= \frac{4000 \times 390 + 7200 \times 20 + 4000 \times 10}{15200}$$

$$\bar{y} = \underline{\underline{200 \text{ cm}}}$$

Merely looking at the I-section we can tell that CG will lie at  $\frac{400}{2} = 200 \text{ cm}$ .

(Pg 10)



We know that L-section is not symmetrical about any axis.

So we find  $\bar{x}$  and  $\bar{y}$

$$\bar{x} = \frac{q_1 x_1 + q_2 x_2}{A}$$

$$\bar{y} = \frac{q_1 y_1 + q_2 y_2}{A}$$

$$q_1 = 2 \times 10 = 20 \text{ cm}^2$$

$$q_2 = 8 \times 2 = 16 \text{ cm}^2$$

$$y_1 = 2 + \frac{10}{2} = 7 \text{ cm}$$

$$y_2 = \frac{2}{2} = 1 \text{ cm}$$

$$x_1 = \frac{2}{2} = 1 \text{ cm}$$

$$x_2 = \frac{8}{2} = 4 \text{ cm}$$

$$A = q_1 + q_2 = 20 + 16 = 36 \text{ cm}^2$$

~~36~~

$$\bar{x} = \frac{a_1 x_1 + a_2 x_2}{A}$$

$$= \frac{20 \times 1 + 16 \times 4}{36}$$

2.33 cm from left line

AG.

$$\bar{y} = \frac{a_1 y_1 + a_2 y_2}{A}$$


$$= \frac{20 \times 7 + 16 \times 1}{36}$$

4.33 cm from bottom

line GF.

PART I  
THEORY OF SIMPLE BENDING OF BEAMS

When an external load acts on a beam, the Shear force and bending moment are set up at all sections of the beam.




Max. moment occurs under the external load

$$\frac{W}{2} \times \frac{L}{2} = \frac{WL}{4}$$

Due to the shear force and bending moment, the beam undergoes deformation. The material of the beam will offer resistance or stresses, against these deformations. These stresses will

## Point load



$$\sum M_B = 0$$

$$R_A L = \frac{WL}{2}$$


$$R_A = \frac{W}{2} = R_B$$

$M_{max}$  occurs under point load

$$M_{max} = R_A \times \frac{L}{2}$$

$$= \frac{WL}{4}$$

## Uniformly distributed load



$$\sum M_B = 0$$

$$R_A L = WL \times \frac{L}{2}$$

$$R_A L = \frac{WL^2}{2}$$

$$R_A = \frac{WL}{2} = R_B$$

$$M_C = R_A L - \frac{WL}{2} \times \frac{L}{4}$$

$$= \frac{WL^2}{2} - \frac{WL^2}{8}$$

$$= \frac{4WL^2 - WL^2}{8}$$

$$= \frac{3WL^2}{8}$$


$$M_C = \frac{2WL^2 - WL^2}{8}$$

$$= \frac{WL^2}{8}$$


with certain assumptions can be calculated.  
The stresses introduced by bending moment are known as bending stresses.

### ASSUMPTIONS OF SIMPLE BENDING

1. The material of the beam is homogeneous (same kind throughout) and isotropic (equal elastic properties in all directions).
2. The value of Young modulus of elasticity is the same in tension and compression.
3. The transverse sections which were plane before bending, remain plane after bending also.
4. The beam is initially straight and all longitudinal filaments bend into circular arcs with a common centre of curvature.
5. The radius of curvature is large compared with the dimensions of cross-section.
6. Each layer of the beam is free to expand or contract, independently of the layer, above or below it.



(a) Before bending



(b) After bending

Fig (a) shows a part of a beam subjected to simple bending. Consider a small length  $dx$  of this part of beam. Consider 2 sections  $AB$  &  $CD$  which are normal to the axis of the beam  $N-N$ . Due to the action of bending moment, the part of length  $dx$  will be deformed as shown in fig (b). From fig (b), it is clear that all layers of the beam, which were originally of the same length do not remain the same length anymore. Top layer  $AC$  has deformed to  $A'C'$ . This layer has been shortened in its length. The bottom layer  $BD$  has deformed to  $B'D'$ . This layer has been elongated.

From fig (b), it is clear that some layers are shortened and some layers are elongated. At a level between top and bottom of the beam, there will be a layer which is neither shortened

not elongated. This layer is known as neutral layer or neutral surface.


This layer in Fig (b) is shown by  $N'-N'$  and fig (c) by  $N-N$ . The line of intersection of the neutral layer on a cross-section of a beam is known as neutral axis (written as NA).

The layers above  $N-N$  (or  $N'-N'$ ) have been shortened and those below, have been elongated. Due to the decrease in lengths of the layers above  $N-N$ , these layers will be subjected to compressive stresses. Due to increase in the lengths of layers below  $N-N$ , these layers will be subjected to tensile stresses.

~~We also see~~ It is also showed that the top layer has been shortened maximum, As we proceed from layer  $N-N$  going up, the decrease in length of the layer decreases. At the layer  $N-N$ , there is no change in length. This means that compressive stress will be maximum at the top layer. Similarly the increase in length will be maximum at the bottom layer. As we proceed from bottom layer towards the layer  $N-N$ , the increase in length of layers decreases. Hence the amount by which a layer increases or decreases in length, depends upon the position of the layer with respect to  $N-N$ . This theory of bending

is known as Theory of simple bending.

Expression for bending stress



Strain Variation Along the depth of Beams

fig a shows a small length  $dx$  of a beam subjected to a simple bending. Due to action of bending, the part of length  $dx$  will be deformed as shown in fig b.

Let  $A'B'$  and  $C'D'$  meet at  $O$

let  $R =$  Radius of Neutral layer  $N'N'$

$\theta =$  Angle subtended at  $O$  by  $A'B'$  &  $C'D'$  produced.

(17)

## Strain Variation

Consider a layer EF at a distance  $y$  below the Neutral layer NM. After bending this layer will be elongated to E'F'

Original length of layer EF =  $dx$

Also length of Neutral layer NM =  $dx$

After bending, the length of Neutral layer N'M' will remain unchanged. But length of layer E'F' will increase.

Hence N'M' = NM =  $dx$

Now from fig (b)

$$N'M' = R \times \theta$$

Radius of N'M' =  $R$

$$\text{and } E'F' = (R+y) \times \theta$$

Radius of E'F' =  $R+y$

But N'M' = NM =  $dx$

$$\text{Hence } dx = R \times \theta$$

Increase in length of the layer EF

$$= E'F' - EF$$

$$= (R+y) \times \theta - R \times \theta$$

$$= (R \times \theta) + y \times \theta - (R \times \theta)$$

$$= y \times \theta$$

$$\text{Strain in layer EF} = \frac{\text{Increase in length}}{\text{Original length}} = \frac{y \times \theta}{R \times \theta}$$

(18)

$$1.0 \text{ Strain in the layer } EF = \frac{y}{R}$$

~~As~~ As  $R$  is constant, hence strain in layer is proportional to the its distance from the neutral axis.

The equation  $\frac{y}{R} = \text{Strain in layer}$  shows the variation of strain along the depth of the beam. The variation of strain is linear.

### Stress Variation

Let  $\sigma = \text{Stress in layer } EF$

$E = \text{Young's modulus of the beam.}$

$$\text{Then } E = \frac{\text{Stress in layer } EF}{\text{Strain in layer } EF}$$

$$E = \frac{\sigma}{\frac{y}{R}}$$

$$1.0 \quad \sigma = E \times \frac{y}{R}$$

$$\sigma = \frac{E}{R} \times y$$

Since  $E$  and  $R$  are constant, therefore stress in any layer is directly proportional to the distance of the layer from the neutral layer. (19) 

The equation  $\sigma = \frac{E}{R} y$  shows the variation of stress along the depth of the beam. The variation of stress is linear.

In the above case, all layers below the neutral layer are subjected to tensile stresses whereas the layers above neutral layer are subjected to compressive stresses. Fig. c shows the stress distribution.

$$\text{Also } \sigma = \frac{E}{R} y$$


$$\therefore \frac{\sigma}{y} = \frac{E}{R} \text{ --- STSP --- See examples } \textcircled{8}$$

### Neutral Axis and Moment of Resistance.

The neutral axis of any transverse section of a beam is defined as the line of intersection of the neutral layer with the transverse section. It is written as N.A.

It has been established that if a section is subjected to pure sagging (positive) moment then, the stresses will be compressive above N.A. and tensile below the N.A. There is no stress at the N.A. \textcircled{20}

The stress at distance  $y$  from N.A is given by



$$\sigma = \frac{E}{R} \times y$$

from the cross section of the beam shown, let N.A be the neutral axis of the section. Consider a small layer at a distance  $y$  from the N.A

let  $dA =$  Area of the layer

Now the force on the layer

$$= \left[ \begin{array}{l} \text{Pressure} \\ \text{Stress} = \frac{F}{A} \end{array} \right]$$

$$= \text{Stress on layer} \times \text{Area of layer}$$

$$= \sigma \times dA$$

$$= \frac{E}{R} \times y \times dA$$

Total force on the beam section is obtained by integrating the above equation

i.e. Total force on the beam

$$= \int \frac{E}{R} \times y \times dA$$

$$= \frac{E}{R} \int y \times dA$$

(21)

~~(21)~~

But for pure bending, there is no force on the section of the beam. (force is zero).

$$i.e. \quad \frac{E}{R} \int y + dA = 0$$

$$\int y + dA = 0 \quad \left[ \text{as } \frac{E}{R} \text{ cannot be zero} \right]$$

$$\int y dA = 0$$

Now  $y \cdot dA$  represents the moment area  $dA$  about N.A.

Hence  $\int y \cdot dA$  represents the moment of entire area of the section about N.A.

But we know that moment of any area about axis passing through its centroid is also equal to zero. Hence N.A. coincides with the Centroidal axis.

Thus the centroid axis of a section gives the position of N.A.

$$\text{Force on layer} = \frac{E}{R} \times y + dA$$

Moment of <sup>resistance</sup> this force about N.A.

$$M = \text{Force on layer} \times y$$

$$M = \frac{E}{R} \times y + dA \times y$$

$$M = \frac{E}{R} \times y^2 + dA$$

(22)

~~(23)~~

Total moment of the force on the section of the beam (or moment of resistance)

$$M = \int \frac{E}{R} + y^2 + dA$$

$$M = \frac{E}{R} \int y^2 + dA$$

Let  $M =$  External moment applied on the beam section.

For equilibrium the moment of resistance offered by the section should be equal to the external bending moment

$$M = \frac{E}{R} \int y^2 dA$$

But the expression  $\int y^2 dA$  represents the moment of inertia of the area of the section about the neutral axis. Let this moment of inertia be

$$I$$
$$M = \frac{E}{R} \times I$$

$$\text{or } \frac{M}{I} = \frac{E}{R}$$

$$\text{but } \frac{\sigma}{y} = \frac{E}{R}$$

(23)

(18)

1.4

$$\frac{M}{I} = \frac{\sigma}{y} = \frac{E}{R}$$

This eqn is applicable to a member which is subjected to a constant bending moment and the member is absolutely

free from shear force

This is known as bending equation. It is the most important eqn in the theory of

single bending, which gives us relation between various characteristics of a beam.

|            |          |
|------------|----------|
| $M =$      | $Nmm$    |
| $I =$      | $mm^4$   |
| $\sigma =$ | $N/mm^2$ |
| $y =$      | $mm$     |
| $E =$      | $N/mm^2$ |
| $R =$      | $mm$     |

Check


$$\frac{M}{I} = \frac{Nmm}{mm^4} = N/mm^3$$

$$\frac{\sigma}{y} = \frac{N/mm^2}{mm} = N/mm^3$$


$$\frac{E}{R} = \frac{N/mm^2}{mm} = N/mm^3$$

(24)

(S)




A rolled steel joist of I-section has dimensions as below. This beam of I-section carries a udl of 40 kN/m run on a span of 10m. Calculate the maximum stress produced



Soln  
 N.A lies at the centre of the I-section since its symmetrical

$y_{max} = \frac{400}{2} = 200 \text{ mm}$



$M_{max} = \frac{wL^2}{8}$  (udl)

$L = 10 \text{ m} = 10 \times 10^3 \text{ mm}$

$w = 40 \text{ kN/m} = 40,000 \text{ N/m}$

$M_{max} = \frac{40,000 \times 10^2}{8}$

$= 500,000 \text{ Nm}$

Moment of Inertia I

$I = \frac{bd^3}{12}$

$I = \frac{200 \times 400^3}{12} - \frac{(200-10) \times 360^3}{12}$

$I = 3.28 \times 10^8 \text{ mm}^4$

Pg 11 (25) (25)

Check deflection from bending equation and use appropriately.

$$\frac{M}{I} = \frac{\sigma_{max}}{y_{max}}$$

$$\sigma_{max} = \frac{M}{I} \times y_{max}$$

$$= \frac{5 \times 10^8 \times 200}{3.28 \times 10^8}$$


$$\sigma = 304.87 \text{ N/mm}^2$$

Asymmetrical section.

A cast iron bracket subjected to bending has cross-section of I-form with unequal flanges as shown in the figure below. Find the position of the neutral axis and moment of inertia of the section about the neutral axis.

If the maximum bending moment on the section is 40 kNm, determine the maximum stress. What is the nature of the stress?

Soln.



Calculate the CG of the section i.e.  $y_{max}$ .

Note:  $y$  = distance of C-G from the bottom line.

$$a_1 = 130 \times 50 = 6500 \text{ mm}^2$$

$$a_2 = 200 \times 50 = 10,000 \text{ mm}^2$$

$$a_3 = 200 \times 50 = 10,000 \text{ mm}^2$$

$$y_1 = 50/2 = 25 \text{ mm}$$

$$y_2 = 50 + 200/2 = 150 \text{ mm}$$

$$y_3 = 250 + 50/2 = 275 \text{ mm}$$



P926

$$\bar{y} = \frac{a_1 y_1 + a_2 y_2 + a_3 y_3}{A}$$

$$A = a_1 + a_2 + a_3 = 26500 \text{ mm}^2$$

$$= \frac{6500 \times 25 + 10000 \times 150 + 10000 \times 225}{26500}$$

$$\bar{y} = 166.51 \text{ mm}$$

Hence the N.A is at a distance 166.51 mm from the bottom face.

$$(2) \quad I = \frac{bd^3}{12}$$

$$I = I_1 + I_2 + I_3$$

$I_1 = \text{MOI of the bottom flange about N.A}$

$= \text{MOI of the bottom flange about an axis passing through its C.G.} + \left[ A_1 \times (\text{Distance of its C.G. from N.A})^2 \right]$

$$\therefore I_1 = \frac{130 \times 50^3}{12} + 6500 (166.51 - 25)^2$$

$$= 1354166.67 + 130163020$$

$$= 131517186.6 \text{ mm}^4$$

~~276~~ **Ps 27**

$$I_2 = 19.0 I \text{ of web about N.A}$$

$$= \frac{50 \times 200^3}{12} + A_2 (166.51 - 150)^2$$

$$= 33333333.33 + 10,000 (166.51 - 150)^2$$

$$+ 272580.1$$

$$= 36059134.33 \text{ mm}^4$$

$$I_3 = 19.0 I \text{ of the top flange about N.A}$$

$$= \frac{200 \times 50^3}{12} + 10000 (y_3 - 166.51)^2$$

$$= 2083333.33 + 10000 (275 - 166.51)^2$$

$$= 119784134.3 \text{ mm}^4$$

$$I = I_1 + I_2 + I_3$$

$$= 131517186.6 + 3$$

$$= 284907234.9$$

(2)

(3)

(28)

Now distance of C.G. from the top fibre

$$= 300 - \bar{y} = 300 - 166.51 \\ = 133.49 \text{ mm}$$

and distance from bottom fibre

$$\text{is } \bar{y} = 166.51 \text{ mm} \quad \text{--- (bigger)}$$

Hence we shall take the value of  $y = 166.51 \text{ mm}$  for maximum bending stress.

Now using equation

$$\frac{M}{I} = \frac{\sigma_{\text{max}}}{y_{\text{max}}}$$


$$\sigma_{\text{max}} = \frac{M}{I} \times y_{\text{max}}$$

$$= \frac{40 \times 10^6}{284907234.9} \times 166.51$$

$$= 23.277 \text{ N/mm}^2$$

~~24~~

29



The stress is compressive because it is a cantilever (bracket).


In case of cantilevers, upper layer is subjected to tensile stress, whereas lower layer is subjected to compressive stress.

~~57~~ 30

Example on ~~Asymmetrical~~ Symmetrical Section

~~A rolled steel joist of I-section~~

A cast iron beam is of I-section as shown below. The beam is SS on a span of 5m. If the tensile stress is not to exceed  $20 \text{ N/mm}^2$ . Find the safe uniform load which the beam can carry. Find also the maximum compressive stress



Soln

Length of beam  $L = 5 \text{ m}$

Max tensile stress  $\sigma_t = 20 \text{ N/mm}^2$

First, calculate the CG of the section  $\bar{y}$

Let  $\bar{y}$  is the distance of CG from the bottom face (flange)

The section is symmetrical about Y-axis

$$A_1 = 160 \times 40 = 6400 \text{ cm}^2$$

$$A_2 = 200 \times 20 = 4000 \text{ cm}^2$$

$$A_3 = 80 \times 20 = 1600 \text{ cm}^2$$

$$y_1 = 40/2 = 20$$

$$y_2 = 40 + 200/2 = 140$$

$$y_3 = 240 + 20/2 = 250$$

$$A = A_1 + A_2 + A_3 = 12000 \text{ mm}^2$$

$$\bar{y} = \frac{A_1 y_1 + A_2 y_2 + A_3 y_3}{A}$$

$$= \frac{1088000}{12000}$$

$$= 90.66 \text{ mm}$$

~~(31)~~ (31)

N.A lies at a distance of 90.66 mm from the bottom face or

$$260 - 90.66 = 169.34 \text{ mm}$$

from the top face.

Mem

M.O.I of the section about N-axis is given by

$$I = I_1 + I_2 + I_3$$

$I_1 =$  M.O.I of bottom flange about N.A

$=$  M.O.I of bottom flange about its C.G +

$$\left[ A_1 \times \left( \text{Distance of its C.G from N.A} \right)^2 \right]$$

$$= \frac{160 \times 40^3}{12} + 6400 (90.66 - 20)^2$$

$$= 853333.33 + 31954147.84$$

$$= 32807481.17 \text{ mm}^4$$

$I_2 =$  M.O.I of web about NA

$=$  M.O.I of web about its C.G

$$+ \left[ A_2 \times \left( \text{Distance of its C.G from N.A} \right)^2 \right]$$

$$= \frac{20 \times 200^3}{12} + 4000 (140 - 90.66)^2$$

$$= 23071075.75 \text{ mm}^4$$

$I_3 =$  M.O.I of top flange about NA

$=$  M.O.I of top flange about

$$\text{its C.G} + \left[ A_3 \times \left( \text{Distance of its C.G from NA} \right)^2 \right]$$

$$= \frac{80 \times 20^3}{12} + \frac{1600}{8000} (250 - 90.66)^2$$

$$= 40676110.29 \text{ mm}^4$$

$$I = I_1 + I_2 + I_3$$

$$= 965554667.21 \text{ mm}^4$$

For a simple supported beam, the tensile stress will be at the extreme bottom fibre and the compressive stress will be at the extreme top fibre

(32) (21)

Here, Max tensile stress

$$\sigma_t = 20 \text{ N/mm}^2$$

$$y_{\text{max}} = 90.66 \text{ mm}$$

i.e.  $y$  is the distance of

the extreme ~~top~~ bottom fibre (where the tensile stress is maximum) from the N.A.

Using the relevant bending equation

$$\frac{M}{I} = \frac{\sigma}{y}$$

$$M = \frac{\sigma}{y} \times I$$

$$= \frac{20}{90.66} \times 96554667.21$$

$$= 21300389.85 \text{ Nmm}$$

Let  $w = \text{udl}$  in  $\text{N/m}$  on the SSB

The max. B.M. is at the centre and equal to

$$\frac{wL^2}{8}$$

$$\therefore M_{\text{max}} = \frac{w \times 5^2}{8}$$

$$= \frac{w \times (25 \times 1000 \text{ mm})}{8}$$

$$M_{\text{max}} = 3125w$$

$$\therefore 21300389.85 = 3125w$$

$$w = \frac{21300389.85}{3125}$$

$$= \underline{\underline{6816.125 \text{ N/mm}}}$$



Maximum Compressive stress

Distance of the extreme top fibre from N.A

$$y_c = 260 - 90.66$$

$$= 169.34 \text{ mm}$$

~~30~~ (33)



$$M = 21300389.85 \text{ Nmm}$$

$$I = 96554667.21 \text{ mm}^4$$

$\sigma_c$  = Max Compressive Stress

$$\frac{M}{I} = \frac{\sigma}{y}$$

$$\sigma = \frac{M}{I} \times y_c$$

$$\sigma_c = \frac{M}{I} \times y_c$$


$$\sigma_c = \frac{21300389.85}{96554667.21} \times 169.34$$

$$= \underline{\underline{37.357 \text{ N/mm}^2}}$$

34

## Home work

A Cast iron beam is of T-section as below. The beam is SS on a span of 8m. The beam carries a ~~total~~ Udl load of  $1.5 \text{ kN/m}$  length on the entire span. Determine the maximum tensile and compressive stresses.



Answer

$$\sigma_t = 258.81 \text{ N/mm}^2$$


$$\sigma_c = 123.08 \text{ N/mm}^2$$

35

Examples (SOM JALHETE Pg 347)

1) A steel wire 5mm  $\phi$  is bent into a circular shape of 5m radius. Det. the max. stress induced in the wire. Take  $E = 200 \text{ GPa}$ .

Soln



$\phi$  of the wire = 5mm

Radius of circular shape = 5m =  $5 \times 10^3 \text{ mm}$

$E = 200 \text{ GPa} = 200 \times 10^3 \text{ N/mm}^2$

The distance b/w the N.A wire and its extreme fibre is given as

$$y_m = \frac{d}{2} = \frac{5}{2} = 2.5 \text{ mm}$$

$$\sigma_{\text{max}} = \frac{E}{R} \times y$$


$$= \frac{200 \times 10^3}{5 \times 10^3} \times 2.5$$

$$\sigma_{\text{max}} = 100 \text{ N/mm}^2$$

(36)

2) A copper wire of 2mm  $\phi$  is required to be wound around a drum. Find the min. radius of the drum, if the stress in the wire is not to exceed  $80 \text{ N/mm}^2$ . Take  $E = 100 \text{ GPa}$  [ $100 \times 10^3 \text{ N/mm}^2$ ]

Soln



$$y_m = \frac{2}{2} = 1 \text{ mm}$$


$$\sigma = 80 \text{ N/mm}^2$$

$$E = 100 \times 10^3 \text{ N/mm}^2$$

$$\therefore 80 = \frac{100 \times 10^3}{R} \times 1$$

$$R = 1.25 \times 10^3 \text{ mm} = 1.25 \text{ m}$$

3) A metallic rod of  $\phi$  10mm is bent into a circular form of radius 4m.  $\sigma_{\text{max}}$  developed in the rod is  $125 \text{ N/mm}^2$ . Find the val. of young modulus of elasticity of the rod material



$$y = \frac{10}{2} = 5$$

$$E = 100 \times 10^3 \text{ N/mm}^2$$

(9)


(4)

Ex 1

A steel plate of width 20mm and thickness 20mm is bent into a circular arc of radius 10m.

Det. the max. stress induced and the bending moment which will produce the maximum stress : Take  $E = 2 \times 10^5 \text{ N/mm}^2$


Soln



bent : either to arc (circular)  
Top layer



or



37

width of plate  $b = 120 \text{ mm}$  thickness of plate  $t = 20 \text{ mm}$  (depth)

$$\text{moment of Inertia} = \frac{bd^3}{12} = \frac{b t^3}{12}$$

$$I = \frac{120 \times 20^3}{12} = 8 \times 10^4 \text{ mm}^4$$

radius of curvature  $R = 10 \text{ m} = 10 \times 10^3 \text{ mm}$

$$E = 2 \times 10^5 \text{ N/mm}^2 \quad \left\{ \text{What is } E? \right\}$$

let  $\sigma_{\text{max}} = \text{Max stress induced}$

$M = \text{bending moment}$

Use the relevant bending equation

$$\sigma = \frac{E}{R} \times y$$

$$\sigma = \frac{E}{R} \times y \quad \text{--- (1)}$$

equation 1 gives the stress at a distance  $y$  from N.A.



Stress will be max, when  $y$  is maximum. But  $y$  will be max. at ~~top~~ the top layer or bottom layer.

$$y_{max} = \frac{t}{2} = \frac{20}{2} = 10 \text{ mm}$$

$$\sigma_{max} = \frac{E}{R} \times y_{max}$$

$$= \frac{2 \times 10^5}{10 \times 10^3} \times 10$$

$$= 200 \text{ N/mm}^2$$

Bending moment  
Using relevant bending eqn

$$\frac{M}{I} = \frac{\sigma}{y}$$

$$M = \frac{\sigma}{y} \times I$$

$$= \frac{200}{10} \times 8 \times 10^3$$

$$= 16 \times 10^5 \text{ Nm}$$

$$= 1.6 \times 10^6 \text{ kNm}$$

$$\text{or } \frac{M}{I} = \frac{E}{R}$$

$$M = \frac{E}{R} \times I$$

$$= \frac{2 \times 10^5}{10 \times 10^3} \times 8 \times 10^4$$

$$= 1.6 \times 10^6 \text{ kNm (as before)}$$

Ex 2

Cal. the  $\sigma_m$  induced in a Cast Iron pipe of external diameter 40mm, of internal diameter 20mm and length 4m when the pipe is supported at its ends and carries a point load of 80N at its centre.


Soln

Ext  $\phi$   $D = 40 \text{ mm}$


Int  $\phi$   $d = 20 \text{ mm}$

length  $l = 4 \text{ m} = 4000 \text{ mm}$

Point load  $W = 80 \text{ N}$




For point load 80N



$$M_{max} = \frac{WL}{4} \text{ how?}$$

$$= 1.6 \times 10^6 \text{ kNm (as before)}$$



$M_{max}$  at C =  $R_A \times \frac{L}{2}$   
 $= \frac{W}{2} \times \frac{L}{2} = \frac{WL}{4}$

$\therefore M_{max} = \frac{80 \times 1000}{4}$   
 $= 80 \times 10^3 \text{ Nmm}$   
 $= 8 \times 10^4 \text{ Nmm}$

Moment of Inertia for  
 Circular pipe,  $I = \frac{\pi d^4}{64}$

For Round

$I$  for rectangular  
 Section  $I = \frac{bd^3}{12}$

$d = \text{depth}$

This is hollow pipe  
 $I$  for hollow pipe

$I = \frac{\pi (D^4 - d^4)}{64}$

$= \frac{\pi (40^4 - 20^4)}{64}$

$= 117809.7 \text{ mm}^4$

Relevant Bending eqn.

$\frac{M}{I} = \frac{\sigma}{y}$

$\sigma = \frac{M}{I} \times y$

~~also  $\sigma$  is max;~~  
 for max  $\sigma$ ;  $y$  has  
 to be maximum

$\therefore y = \frac{D}{2} = \frac{40}{2} = 20 \text{ mm}$



(39)

~~(38)~~


~~(37)~~

$$\sigma_{\text{max}} = \frac{M}{I} + y_{\text{max}}$$

$$= \frac{8 \times 10^4}{117809.7} \times 20$$

$$= 13.58 \text{ N/mm}^2$$

$$= 13.58 \text{ N/mm}^2$$



### SECTION MODULUS (Z)

It is also called modulus of a section. It is defined as the ratio of moment of inertia of a section about n.a. to the distance of the outermost layer from the n.a.

Mathematically

$$Z = \frac{I}{y_{\text{max}}}$$

But from Bending equation

$$\frac{M}{I} = \frac{\sigma}{y}$$

Stress  $\sigma$  is max

when

$y$  is max

$$\therefore \frac{M}{I} = \frac{\sigma_{\text{max}}}{y_{\text{max}}}$$

$$M = \sigma_{\text{max}} \cdot \frac{I}{y_{\text{max}}}$$

$$\therefore M = \sigma_{\text{max}} Z$$

$$\therefore \sigma_{\text{max}} = \frac{M}{Z}$$

~~M = moment~~  $M$  is the  $M_{\text{max}}$  or moment of resistance offered by the section.

(40)

(18) (9)

Hence

$$M = \sigma_{max} Z$$

Moment of resistance  $M$  is


maximum when  $Z$  is

maximum. Hence

Section modulus  $Z$

represents the strength of the section.

$Z$  for rectangular section




$$I = \frac{bd^3}{12}$$

$$y_{max} = \frac{d}{2}$$

$$\text{Hence } Z = \frac{I}{y_{max}} = \frac{bd^3}{12} \div \frac{d}{2}$$

$$Z = \frac{bd^3}{12} \times \frac{2}{d} = \frac{bd^2}{6}$$

$Z$  for rectangular hollow section




$$I = \frac{BD^3}{12} - \frac{bd^3}{12}$$

$$= \frac{1}{12} [BD^3 - bd^3]$$

$$y_{max} = \frac{D}{2}$$

$$Z = \frac{1}{12} [BD^3 - bd^3] \times \frac{2}{D}$$


$$Z = \frac{BD^3 - bd^3}{60}$$



(41)

(10)

### Circular Section




$$I = \frac{\pi d^4}{64}$$

$$y_{\text{max}} = \frac{d}{2}$$

$$Z = \frac{I}{y_{\text{max}}} = \frac{\pi d^4}{64} \times \frac{2}{d}$$

$$Z = \frac{\pi d^3}{32}$$

### Circular Hollow



$$I = \frac{\pi D^4}{64} - \frac{\pi d^4}{64} ; y_{\text{max}} = \frac{D}{2}$$

$$Z = \frac{\pi D^4}{64} - \frac{\pi d^4}{64} \times \frac{2}{D}$$

$$= \frac{\pi [D^4 - d^4]}{64} \times \frac{2}{D}$$

$$Z = \frac{\pi [D^4 - d^4]}{32D}$$


42

22

### Example

A bracket (cantilever) of length 2m having a load of 2kN at its free end

A Cantilever beam of <sup>rectangular</sup> section 40mm x 60mm, length 2m having a load of 2kN at its free end. Calculate the maximum stress induced in the beam.



Section modulus of a rectangular section is given by

$$Z = \frac{bd^2}{6}$$

$$b = 40 \text{ mm}, d = 60 \text{ mm}$$

$$Z = \frac{40 \times 60^2}{6} \\ = 24000 \text{ mm}^3$$

Maximum bending moment for a Cantilever beam is at the fixed end.

$$M_{\text{max}} = WL$$

$$W = 2 \text{ kN} = 2000 \text{ N}$$

$$L = 2 \text{ m} = 2000 \text{ mm}$$

$$M_{\text{max}} = 2000 \times 2000 \\ = 4 \times 10^6 \text{ Nmm}$$

Maximum stress or stress at failure


$$\sigma_{\text{max}} = \frac{M_{\text{max}}}{Z}$$

$$= \frac{4 \times 10^6}{24000}$$

$$\sigma_{\text{max}} = 166.67 \text{ N/mm}^2$$

Ans

Q129  
A rectangular beam 60mm wide and 150mm deep is SS over a span of 4m. If the beam is subjected to UDL of 4.5 kN/m. Find the maximum bending stress induced in the beam.



We know that  $Z$  for a rectangular section.

$$Z = \frac{bd^2}{6}$$

$$= \frac{60 \times (150)^2}{6}$$

$$= 225 \times 10^3 \text{ mm}^3$$

9mm for SS is subjected to udl load.

$$M_{\text{max}} = \frac{wL^2}{8} = \frac{4.5 \times (4 \times 10^3)^2}{8}$$

$$= 9 \times 10^6 \text{ Nmm}$$

$$\sigma_{\text{max}} = \frac{M}{Z}$$


$$= \frac{9 \times 10^6}{225 \times 10^3}$$

$$= 40 \text{ MPa}$$

Q130

A rectangular beam 60mm wide and 150mm deep is simply supported over a span of 6m. If the beam is subjected to central point load of 12kN, find the maximum bending stress induced in the beam, section.

Solution



We know that  $Z$  for rectangular section

$$Z = \frac{bd^2}{6}$$

$$= \frac{60 \times (150)^2}{6}$$

$$= 225 \times 10^3 \text{ mm}^3$$

9mm for SS is with point load at the centre of the beam

$$M_{\text{max}} = \frac{wL}{4}$$

$$= \frac{12 \times 6 \times 10^3}{4}$$

$$= 18 \times 10^6 \text{ Nmm}$$

P56


P514

Maximum bending stress values

$$\sigma_{max} = \frac{M}{Z} = \frac{18 \times 10^6}{225 \times 10^3} = 80 \text{ N/mm}^2$$

80 MPa

③ A rectangular beam 200mm deep and 300mm wide is SS over a span of 8m. What UDL per metre the beam may carry, if the bending stress is not to exceed 120 N/mm<sup>2</sup>.



Soln

Given

Depth of beam d = 200mm

Width of beam b = 300mm

Length of beam L = 8m

L = 8000mm

Max bending stress

$$\sigma_{max} = 120 \text{ N/mm}^2$$

Let w = UDL per mm/length over the beam.

$$1000 \text{ N} = 1 \text{ kN}$$

$$w = 8000,000 \text{ kN}$$

Section modulus  $Z = \frac{bd^2}{6}$

$$= \frac{300 \times 200^2}{6} = 2 \times 10^6 \text{ mm}^3$$

M<sub>max</sub> for UDL

$$M = \frac{wL^2}{8} = \frac{w \times (8000)^2}{8}$$

$$M = w \cdot 8000000 \text{ Nmm} = 8w \text{ Nm}$$

$$M = 2w \cdot 8000 \text{ Nmm} = 16000w \text{ Nmm}$$

$$\sigma_{max} = \frac{M}{Z}$$

$$w \cdot 8000 \text{ Nmm}$$

$$M = 2 \cdot \sigma_{max} \cdot Z$$

$$4500 \text{ Nmm} = \frac{4500 \text{ N}}{1000 \text{ mm}} = 4.5 \text{ N/mm}$$

$$4.5 \text{ kN/m} = 4500 \text{ N/m}$$

10mm - 1cm  
 10cm - 1dec  
 10dec - 1m

$$1000 \text{ mm} = 1 \text{ m}$$

110

$$8000w = 120 \times 2 \times 10^6$$

$$w = \frac{120 \times 2 \times 10^6}{8000}$$

$$w = 30 \times 1000 \text{ N/mm}$$

$$w = 30 \text{ kN/mm}$$

Q A cantilever of length 2 metre fails when a load of 2kN is applied at the free end. If the section of the beam is 40mm x 60mm. Find the stress at the failure.

Given


$$\text{length } L = 2\text{m} = 2 \times 10^3 \text{ mm}$$

$$\text{load } W = 2\text{kN} = 2000 \text{ N}$$

Section of beam is 40mm x 60mm

$$\text{width } b = 40\text{mm}$$

$$\text{depth } d = 60\text{mm}$$




beam section

$$\sigma_{\text{max}} = \frac{M_{\text{max}}}{Z}$$

$$Z = \frac{bd^2}{6} = \frac{40 \times 60^2}{6}$$

$$= 2.4 \times 10^4 \text{ mm}^3$$

$M_{\text{max}}$  for a cantilever beam as shown below



$$M_{\text{max}} = W \times L$$

$$= 2 \times 10^3 \times 2 \times 10^3$$

$$= 4 \times 10^6 \text{ Nmm}$$

$$\sigma_{\text{max}} = \frac{4 \times 10^6}{2.4 \times 10^4}$$

$$\sigma_{\text{max}} = 1.6 \times 10^2 \text{ N/mm}^2$$

$$= 166.6 \text{ N/mm}^2$$

WE? - Strain - To pull, draw, or stretch tight

WE 307 Tuesday 10/4/2018

### STRAIN ENERGY -

When a body is strained, energy is absorbed in the body. This energy is called Strain Energy.

The straining effect may be due to gradually applied load or suddenly applied load or load with impact.

Hence the strain energy will be stored in the body when the load is applied gradually or suddenly or with an impact.

The strain energy stored in the body is equal to the work done by the applied load in stretching the body.

### DEFINITIONS

#### Resilience

Resilience - The total strain energy stored in a body is commonly known as Resilience. Whenever the straining force is removed from the strained body, the body is capable of doing work. Hence the Resilience is also defined as the capacity/ability of a strained body for doing work on the removal of the straining force.

Resilience is the positive ability of a system or ~~resilience~~ a physical property of a material that can resume its shape after being stretched or deformed.

#### Elasticity


Proof Resilience - The maximum strain energy stored in a body is known as proof resilience. The strain energy stored in the body will be maximum when the body is stressed up to elastic limit. Hence the proof resilience is the quantity of strain energy stored in a body when strained up to elastic limit.

In physics - To cause distortion/deformation by applying an external force.

Modulus of Resilience: It is defined as the proof resilience of a material per unit volume. It is an important property of a material, mathematically

$$\text{Modulus of resilience} = \frac{\text{Proof resilience}}{\text{Volume of the body}}$$

EXPRESSION FOR STRAIN ENERGY STORED IN A BODY WHEN THE LOAD IS APPLIED GRADUALLY



The figure shows load extension diagram of a body under tensile test upto elastic limit. The tensile load  $P$  increases gradually from zero to the value of  $P$  and the extension of the body increases from 0 to  $x$  value.

The load  $P$  performs work in stretching the body. This work will be stored in the body as strain energy which is recoverable after the load  $P$  is removed.

Let  $P$  = Gradually applied load  
 $x$  = Extension of the body.

$A$  = Cross-sectional area

$L$  = length of the body

$V$  = Volume of the body

$E$  = Young's Modulus

$\sigma$  = Stress induced in the body and

$U$  = Strain energy stored in the body.

Now,

Work done by the load = Area of load extension curve [Shaded area]

$$W = \text{Area of } \triangle ONM = \frac{1}{2} \times P \times x \quad \text{--- (1)}$$

But

$$\text{load [force]} P = \text{Stress} \times \text{Area}$$

$$P = \sigma A \quad \left[ \sigma = \frac{P}{A} \right]$$

and extension,  $x = \text{strain} \times \text{length}$   
 from strain =  $\frac{x}{L}$

1.0  

$$\epsilon = \frac{\sigma_{\text{stress}}}{E} \times L$$
 from  

$$\text{Strain} = \frac{\text{Stress}}{E}$$

1.0  

$$\epsilon = \frac{\sigma}{E} \times L$$

Substituting the values of  $P$  and  $x$  in eqn (1)

1.0  
 Work done =  $\frac{1}{2} \times \sigma \cdot A \times \sigma L$

1.0  

$$= \frac{\sigma^2}{2E} \cdot A \cdot L$$

1.0  

$$= \frac{\sigma^2}{2E} \cdot V \quad [V = A \cdot L]$$

But the work done by the load in stretching the body is equal to strain energy stored in the body

$\therefore$  Energy stored in the body,

1.0  

$$U = \frac{\sigma^2}{2E} \times V$$


Proof resilience = maximum energy stored in the body without permanent deformation (i.e. upto elastic limit)

Hence if the stress  $\sigma$  is taken to the elastic limit, we get proof resilience

1.0  
 Proof Resilience =  $\frac{\sigma^2}{2E} \times \text{Volume}$

$\sigma^*$  = stress upto elastic limit

1.0  
 Modulus of Resilience =  $\frac{\text{Total Strain Energy}}{\text{Volume}}$



When the load is applied suddenly

When the load is applied suddenly, the load (force)  $P$  is constant throughout the process of the deformation of the body, i.e. the extension of the body takes place

1.0  
 Work done by the load = Load  $\times$  Extension  

$$= P \times x$$

But we know that the max strain energy stored (i.e. energy stored upto elastic limit) in a body is given by

1.0  

$$U = \frac{\sigma^2}{2E} \times V$$

1st

$$\frac{\sigma^2}{2E} \times A \times L = P \times x$$

1st

$$\frac{\sigma^2}{2E} \times A \times L = P + \frac{\sigma}{E} \times L$$

$$\frac{\sigma}{2} \times A = P$$

$$\sigma = 2 \times \frac{P}{A}$$

From the above equation it is clear that the maximum stress induced due to suddenly applied load is twice the stress induced when the same load is applied gradually.

Ex 1

A tensile load of 60 kN is gradually applied to a circular bar of 4 cm diameter and 5 m long. If the value of  $E = 2 \times 10^5 \text{ N/mm}^2$  determine:

- (i) stretch in the rod
- (ii) stress in the rod
- (iii) strain energy absorbed by the rod

Solution

Gradually applied load  $P = 60 \text{ kN}$   
 $= 60,000 \text{ N}$

Dia of rod  $\cdot d = 4 \text{ cm} = 40 \text{ mm}$

$$\therefore \text{Area} = \frac{\pi d^2}{4} = 1256.64 \text{ mm}^2$$

$$A = \pi r^2 \quad r = \frac{D}{2}$$

$$A = \pi \left(\frac{D}{2}\right)^2 = \frac{\pi D^2}{4}$$

$$A = \frac{\pi \times 40^2}{4} = 1256.64 \text{ mm}^2$$

length of the rod  $L = 5 \text{ m} = 5000 \text{ mm}$

$$\text{Volume of the rod } V = A \times L$$

$$= 1256.64 \times 5000$$

$$= 6.2832 \times 10^6 \text{ mm}^3$$

Young modulus  $E = 2 \times 10^5 \text{ N/mm}^2$

Let  $x$  = stretch or extension in the rod

$\sigma$  = stress in the rod

$U$  = strain energy absorbed by the rod.

$$\sigma = \frac{P}{A} = \frac{60000}{1256.64} = 47.746 \text{ N/mm}^2$$

$$x = \frac{\sigma \times L}{E}$$

$$= \frac{47.746 \times 5000}{2 \times 10^5} = 1.19 \text{ mm}$$

$$= 1.19 \text{ mm}$$

$$U = \frac{\sigma^2}{2E} \times V$$

$$= \frac{47.746^2}{2 \times 2 \times 10^6} \times 2 \times 10^6 \pi$$

$$= 35810 \text{ Nmm}$$

$$U = \underline{\underline{35.81 \text{ Nm}}}$$

(2) If in example 1, the tensile load of 60kN is applied suddenly determine,

(i) maximum instantaneous stress induced

(ii) instantaneous elongation in the rod

(iii) strain energy absorbed in the rod

(i) Maximum instantaneous stress induced

$$\sigma = 2 \times \frac{P}{A}$$

$$= 2 \times \frac{47.746}{\pi}$$

$$= 95.493 \text{ N/mm}^2$$

(ii) Instantaneous elongation in the rod

$$e = \frac{\sigma}{E} \times L = \frac{95.493}{2 \times 10^6} \times 5000$$


$$= 2.38 \text{ mm}$$

(iii)  $U = \frac{\sigma^2}{2E} \times V = \frac{95.493^2}{2 \times 2 \times 10^6} \times 2 \times 10^6 \pi$

$$1432384 \text{ Nmm} = 143.2384 \text{ Nm}$$

## QVE 307

EXPRESSION FOR STRAIN ENERGY STORED IN A BODY WHEN LOAD IS APPLIED WITH AN IMPACT



Consider a vertical rod fixed at the upper end and having a collar at the lower end as shown above.

Let the load be dropped from the height on the collar.

Due to this impact load, there will be an extension on the rod.

Let \$P\$ = load dropped (i.e. load applied with impact.)

\$L\$ = length of the rod

\$A\$ = cross-sectional area of the rod

\$V\$ = Volume of the rod

$h$  = Height through which load is dropped

$\delta L$  = Extension of the rod due to load  $P$

$E$  = Modulus of elasticity of the material rod

$\sigma$  = Stress induced in the rod due to impact load.

Then

the strain in the bar is

given by

$$\text{Strain } \epsilon = \frac{\text{Stress } \sigma}{E}$$

$$\frac{\delta L}{L} = \frac{\sigma}{E}$$

$$\delta L = \frac{\sigma}{E} \times L$$

Work done by the load =  
Load  $\times$  distance moved  
=  $P(h + \delta L)$

The strain energy stored by the rod =

$$U = \frac{\sigma^2}{2E} \times V$$

$$U = \frac{\sigma^2}{2E} \times AL$$

Equating

But work done by the load = Strain energy stored by the rod

$$P(h + \delta L) = \frac{\sigma^2}{2E} \cdot AL$$

$$P \left[ h + \frac{\sigma \cdot L}{E} \right] = \frac{\sigma^2}{2E} \cdot AL$$

$$Ph + \frac{P \cdot \sigma \cdot L}{E} = \frac{\sigma^2}{2E} \cdot AL$$

$$\frac{\sigma^2}{2E} \cdot AL - \frac{P \cdot \sigma \cdot L}{E} - Ph = 0$$

multiplying by  $\frac{2E}{AL}$

$$\sigma^2 - \frac{2P}{A} \sigma - \frac{2PEh}{AL} = 0$$

$$\sigma^2 - \frac{2P}{A} \sigma - \frac{2PEh}{AL} = 0$$

Solving Quadratically

$$\sigma = \frac{2P}{A} + \sqrt{\left(\frac{2P}{A}\right)^2 + 4 \cdot \frac{2PEh}{AL}}$$

$$\sigma = \frac{P}{A} + \sqrt{\frac{4P^2}{A^2} + \frac{8PEh}{AL}}$$

$$\sigma = \frac{2P}{A} + \sqrt{\frac{4P^2}{A^2} + \frac{4 \cdot 2PEh}{AL}}$$

2

10

$$\sigma = \frac{2P}{A} \pm \frac{\left( 2 \sqrt{\frac{P^2}{A^2}} + 2 \sqrt{\frac{2PEh}{AL}} \right)}{2}$$

$$\sigma = \frac{P}{A} \pm \sqrt{\left(\frac{P}{A}\right)^2 + \frac{2PEh}{A \cdot L}}$$

~~$$= \frac{P}{A} + \frac{P}{A} + \frac{2AEh}{A \cdot L}$$~~

~~$$\sigma = \frac{P}{A} + \sqrt{\frac{P^2 \times A^2}{A^2 \cdot P^2} + \frac{2PEh \times A^2}{AL \cdot P^2}}$$~~

~~$$\left( \frac{P}{A} + \sqrt{1 + \frac{2AEh}{PL}} \right)$$~~

$$\sigma = \frac{P}{A} \left( 1 + \sqrt{1 + \frac{2AEh}{PL}} \right)$$

After knowing value of  $\sigma$  the strain energy can be obtained.



neglecting -ve root

But

If  $h$  is very small in comparison with  $L$

Then

$$\text{work done} = P \cdot h$$

100

$$Ph = \frac{\sigma^2 \cdot AL}{2E}$$

$$\sigma^2 = \frac{2EPh}{AL}$$

$$\sigma = \sqrt{\frac{2EPh}{A \cdot L}}$$

But in case  $h = 0$

no height

We get

$$\sigma = \frac{P}{A} \left( 1 + \sqrt{1+0} \right)$$

$$\sigma = \frac{P}{A} (1+1)$$

$$\sigma = \frac{2P}{A}$$